



SILVET[®] P for Plastics



Since its introduction, SILVET[®] has become the most widely recognized technology for incorporating aluminum into plastics. This technology provides aluminum pigment in a safe pellet or granule form, suitable for a wide range of functional and aesthetic applications. The current SILVET[®] E and E1 products have gained global acceptance due to their ease of handling and wide polymer compatibility. Provided with a high metal content, SILVET[®] allows the formulator considerable freedom when creating metallic effects.

In order to improve the compatibility of Silberline aluminum with engineering thermoplastics, Silberline has developed the SILVET[®] P line of products. This family of pigments is designed for increased suitability, clarity and aesthetics in this class of polymers. In some cases, SIL-VET[®] P maintains polymer physical properties better than the same polymer pigmented with other types of carriers.

Product Description

SILVET[®] P grades are manufactured as highly concentrated granules that are typically 2.5 millimeters in diameter. The final product results in highly concentrated metal pigment (80% aluminum, by weight) with a low VOC content. The carrier system affords processors a wide range of temperature profiles while maintaining clarity and function.

Guide for Use of SILVET[®] P

Compatibility with Polyolefins

SILVET[®] P is not recommended for use with polyolefin resins. SILVET[®] E, SILVET[®] E1, or SILVEX[®] aluminum pigments should be used to achieve the best compatibility with polyolefins.

Drying

SILVET[®] P may be dried with polymers during the moisture-removal process provided that the temperature is not above the softening point of SILVET[®]. SILVET[®] P may also be tray-dried using a forced-air oven at 195°F (90°C) for one hour. Take care not to exceed the recommended drying time or temperature.

Pre-Blending

SILVET[®] P may be added at the hopper after simple drum tumbling of the product in the host resin. This method may lead to color variation due to a potential for separation of components in the processing hopper. In this case, a small amount of mineral oil or plasticizer may help to prevent parting.

Incorporation Methods

The most suitable method for introduction of SILVET[®] P is by a gravimetric feeder directed to the hopper of the processing machine. Loss-in-weight belt feeders may also be used since SIL-VET[®] P is a low dusting pigment. These addition methods are designed to meter the granules

SILVET[®] P for Plastics



accurately, even if they are non-uniform in length. The use of volumetric feeders is not recommended. This type of incorporation relies on a uniform length and volume of granules. In the event that a volumetric feeder must be used, processing can be improved by screening the granules through a 0.25 inch mesh prior to addition to the feeder. When using a volumetric feeder, it is suggested that the SILVET[®] feed charge be measured during the run to make certain the amount is consistent.

Compounding Extrusion

When preparing color concentrates or master batches, high-shear, melt mixing is often employed to ensure proper dispersion of chromatic pigments. However, this same technique will have an undesirable graying effect on aluminum pigments. Low-shear incorporation is essential to retain the desired metallic effect in finished parts. As with SILVET[®] E1, SILVET[®] P can be added to the extruder at a down-stream location. The advantage of using this technique is that the aluminum pigment is introduced to the molten polymer after high-shear processing is complete.

Direct Extrusion

Due to the small pellet size and ease of dispersion of SILVET[®] P, it may be added directly to the injection molding or extrusion process without pre-processing. When SILVET[®] P is used in this manner, it is recommended that the equipment profile be evaluated to complete extension of the pigment. Be aware that fine grades are more likely to create streaks in finished parts than coarser flakes. In the event that color variation is observed, the use of a pigment concentrate or pre-compounded resin is advised.

Additional Information

The standard unit size for SILVET[®] P is 55 pounds/25 kilograms, vacuum-sealed in a vaporbarrier plastic bag and encased in a cardboard box. To maintain maximum shelf life, closing the vapor barrier bag securely after each use is recommended.

For product technology and application questions, contact Silberline's Technical Service department at 570-668-2773 or toll-free at 877-492-7881. For samples, product availability and pricing, contact your local Silberline representative or call us toll-free at 800-348-4824.

SILVET[®] P for Plastics





United States and Canada:

Tel: 1-800-348-4824 order@silberline.com

International Orders:

Tel: 570-668-6050 intorder@silberline.com

For All General Inquiries / Correspondence, and Samples:

Tel: 1-570-668-6050 Fax: 1-570-668-2621 samples@silberline.com

Technical Service Department:

Tel: 1-877-492-7881 Fax: 1-570-668-4227 technology@silberline.com

SILVET[®] P for Plastics

Contact Us:

Silberline Global

Headquarters 130 Lincoln Drive PO Box B Tamaqua, PA 18252 Phone: 570-668-6050 Toll-Free (USA & Canada): 800-348-4824 Fax: 570-668-0197 E-Mail: order@silberline.com



Ernest Scheller III Center for Technical Functions & Advanced



PO Box 152 Tamaqua, PA 18252 Phone: 570-668-2773 Toll-Free (USA & Canada): 877-492-7881 Fax: 570-668-4227

Silberline Limited

Manufacturing 36 Progress Avenue

Banbeath Road Leven, Fife Scotland KY8 5HD Phone: 44-1-333-424734 Fax: 44-1-333-421369 E-Mail: euinfo@silberline.com



Silberline Asia Pacific Pte. Ltd.

50 Science Park Road #04-01/02 The Kendall Singapore Science Park II Singapore 117406 Phone: 65-6411-0170 Fax: 65-6779-0080 E-Mail: sapmkt@silberline.com



Silberline Brasil Limitada

Rua Dr. Tirso Martins, 100, Cj. 701 Vila Mariana Sao Paulo – Cep. 04120-050 Brazil Phone: 55-11-3562-2780 Fax: 55-11-3562-2783



Silberline Pigmentos, SRL de CV

Blvd. Atlixcayotl Torre Bosques II #5320-200 Reserva Territorial Atlixcayotl San Andres Cholula Puebla – CP 72810 Mexico Phone: 52-222-2252774

Silberline Pigment (Suzhou) Company Limited

Suchun Industrial Area 428 Xinglong Street, Unit 26B Suzhou, China 215126 Phone: 86-512-67333150 Fax: 86-512-62723540

Silberline Specialty Effect Pigments India Private Limited Plot No. 248

Jawahar Co-Op Industrial Estate Kamothe, Panvel—410 209 Dist: Raigad Maharashtra, India Phone: 91-99-2076-7723

This 2012 edition supersedes all previous editions.

©2010-2012 Silberline. All rights reserved. The Silberline "S" logo, Silberline®, The Global Supplier of Effect PigmentsSM, and all products denoted with an ® or ™ are trademarks or registered trademarks of Silberline Manufacturing Company, Inc., and/or its affiliates.

All statements, information and data presented herein are believed to be accurate and reliable, but are not to be taken as a guarantee, expressed warranty or implied warranty of merchantability or fitness for a particular purpose or use, all of which are hereby disclaimed, or as a representation express or implied, for which Silberline assumes legal responsibility, and they are offered solely for your consideration, investigation and verification. Individual product information and material safety data sheets are available from Silberline upon request and must be referred to because of potential serious hazards associated with the use of these products. Assistance in grade selection can be obtained through your local Silberline representative. For product formulations and assistance, contact Silberline's Technical Service/Product Applications Department. Silberline makes no guarantee, warranty or implied warranty of merchantability or fitness for a particular purpose or use regarding the mixture of the products referred to herein with other ingredients, whether or not performed in accordance with guidelines established by Silberline, all of which are hereby disclaimed.